



# **Feature Description Document**

Assigning a Static IP address to IXM Devices



## **Purpose**

This document outlines the process of assigning a static IP address to an IXM device.

## **Applies to**

TITAN	TFACE	TOUCH 2	SENSE 2	MERGE	MYCRO	MERGE CR
All Devices						


## **Description**

IXM WEB allows a user to change the device IP mode from DHCP to Static andto provide an IP address.



## **Assign Static IP Address from IXM WEB**

1. From **Home** >> Click the **Device** tab >> Select **Device** >> Select the **Communication** navigation tab. >> And Expand **Ethernet**.




2. Change IP Mode from DHCP to **Static**.






3. Provide the Static IP address and click Apply.




4. Upon completion of the process, a confirmation message will be displayed.





#### Assign a Static IP Address from the Device LCD


1. Swipe to the **Communication** app. Tap on the **Communication** icon. The device will prompt for device security authentication before opening the app.



INVIXIUM XAD-FDD-518-02G




#### 2. Tap Ethernet.





3. Change Mode to **STATIC** & provide the required details. IP Address, Subnet Mast & Default Gateway are mandatory fields.



4. Tap the **Save** icon on the top right to store the settings.



#### **Support**

For more information relating to this Feature Description document, please contact us at <a href="mailto:support@invixium.com">support@invixium.com</a>

#### **Disclaimers and Restrictions**

This document and the information described throughout are provided in their present condition and are delivered without written, expressed, or implied commitments by Invixium Inc. and are subject to change without notice. The information and technical data herein are strictly prohibited for the intention of reverse engineering and shall not be disclosed to parties for procurement or manufacturing.

This document may contain unintentional typos or inaccuracies.

#### **TRADEMARKS**

The trademarks specified throughout the document are registered trademarks of Invixium Access Inc. All third-party trademarks referenced herein are recognized to be trademarks of their respective holders or manufacturers.

Copyright © 2022, INVIXIUM. All rights reserved.